

Full Spectrum Solutions

UltraLux Remote Control Table Lamp

Assembly Instructions

Item: UL8130RCD

Please be sure to read all warning instructions before using your lamp, in order to ensure your safety and maximize lamp life.

Lamp Assembly Instructions

1. Lay out lamp parts on the floor as shown in illustration.
2. Thread the **Screw Rod** into the **Screw Rod Holder**.
3. Place the **Top Cap** on top of the **Shade** through the **Screw Rod**, then tighten it with the **Finial Cap**.
4. Place the **Light Bulbs** into the **Light Bulb Socket**.

Function of the Dimmer Switch and Remote Control

1. 1st Touch: Turn on the light.
2. 2nd Touch (hold down): Fade gradually to dimmest setting.
3. 3rd Touch: Turn off the light.

Operating Range and Angle (open field)

1. Up to 9.8' operating range.
2. Up to 90° operating angle.

WARNING:

DO NOT, under any circumstance, touch the bulb or glass cover with bare hands. Always unplug the electrical cord before replacing the bulb, and allow sufficient time for the bulb to cool down.

